
Laura Ashley

Provencale Tall Chest

Thank you for purchasing this product. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



Please ensure instructions are read in full before commencing with this product.

Necessary Tools



Screwdriver not supplied



Please check the pack contents before you begin. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

Safety Advice and Assembly Recommendations

- Do not stand or lean on this product.
- Make sure the area is clear when unpacking and positioning this product.
- This product is **heavy**, it should be assembled as near as possible to the point of use.
 - **Take care when lifting** to avoid personal injury and or damage to the product.
- Keep small children/pets away from assembly area. This product has small component parts that are a choking hazard.
- Make sure you assemble this product correctly as per the instructions and ensure all fittings are tight.
- A minimum of two persons is require to lift the Drawer Chest into position
- We recommend that the packaging is used to protect the surfaces during assembly.

Hardware and Wall Fixing Pack

A	Screws Ø8 x 2" x 8	В	Washer x I	
С	Strap x I	D	Screws Ø8 x ¾" x I	

Parts checklist









2. Plinth x I

Wall fixing - if in doubt seek professional advice




Wood

If fixing to wood make sure that it isn't chipboard as screws can easily pull away from the core structure



Brick or Masonry

wall is sound



Cavity wall

Use an appropriate wall plug Special toggle wall plugs are provided you are sure your needed. Seek expert advice

To avoid any risk of tipping, this unit must be safely secured to the wall (See Wall Mounting Instructions)

Wall Mounting Instructions

- 1. Determine which side of the unit will have the easiest access, and secure the **Wall Fixing Strap** to one of the pre-drilled holes in the back panel (Fig 2) with the **Screw** (D) and **Washer** (B) (See illustration).
- 2. Place the unit in the desired position and move it approximately 5cm away from the side with the fixing strap.
- 3. Secure the loose end of the **Wall Fixing Strap** to the wall using a suitable fixing (**NotSupplied**) and move the unit back into position, to hide the strap. **Before drilling, check for any hidden water pipes or electrical wires.**
- 4. If for any reason you need to move your furniture, simply remove the wall fixing screw.




Fig I
Lay the unit on its back. We recommend that the packaging is used to protect the surfaces during this process.

Place the plinth onto the bottom of the unit (Align the pre drilled holes on the plinth with the pilot holes on the base panel) Secure the plinth using **8 Screws (A)**. Tighten with screw driver.

Fig 2
Carefully turn the assembled cabinet upright onto its feet.

A minimum of two persons will be required to do this.

Care and Maintenance. Please refer to Laura Ashley Care Guide

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE If you have any queries with this product please contact

Laura Ashley Customer Services. Tel: 08719835999

www.lauraashley.com